

The following items are required to operate the PC Control:

- Windows compatible PC
- Windows 98SE, 2000, ME, XP Home edition, XP Professional or 2003
- Available USB 1.0 (or greater) port
- 900 MHz CPU
- CD-ROM drive, 64 MB RAM, 20 MB free hard disk space
- 1024 x 768 64k color display/monitor (800 x 600 minimum)
- Keyboard and pointing device (mouse)
- Internet connectivity (high speed) to use weather-based scheduling (Scheduling Advisor) & get software updates
- Optional Win compatible audio
- Optional means to obtain digital photos:
  - USB cable & software for digital camera, or
  - flash memory card reader compatible with memory card of digital camera